

ST9 SPORT TAB INSTALLATION INSTRUCTIONS SUPPLEMENT

READ INSTRUCTIONS COMPLETELY BEFORE BEGINNING INSTALLATION

Substitute the following instructions for Step 2 in the standard "Trim Tab Installation Instructions."
Also please read the important note below regarding boats kept in salt water.

Step 2 — Attach the mounting plates and trim plane with #14 x 1 ½" stainless steel screws along the bottom of the transom. (See Figure 3). Make ⅜" pilot holes for mounting screws. Assemble mounting plates and tab, dip screws in marine epoxy before running in. Position trim tab between mounting plates before running screws tight. Snug screws down to secure mounting plates and trim tab to transom.

IMPORTANT NOTE FOR BOATS KEPT IN SALT WATER: The black finish of the trim tabs provides a barrier from electrolytic action. However, if the boat is kept in salt water for long periods of time, a zinc anode must be applied to the top side of each tab. To provide protection, the zinc must make good contact with the stainless steel. Therefore the coating under the zinc must be removed. Do not ground the tabs to other underwater appendages. The black finish does not provide anti-fouling protection and should be painted with anti-fouling paint if such protection is desired.



Bennett Marine • 550 Jim Moran Blvd • Deerfield Beach, FL 33442
Ph: 954-427-1400 • Fax: 954-480-2897 • Email: info@BennettTrimTabs.com
www.BennettTrimTabs.com

ST9 SPORT TAB INSTALLATION INSTRUCTIONS SUPPLEMENT

READ INSTRUCTIONS COMPLETELY BEFORE BEGINNING INSTALLATION

Substitute the following instructions for Step 2 in the standard "Trim Tab Installation Instructions."
Also please read the important note below regarding boats kept in salt water.

Step 2 — Attach the mounting plates and trim plane with #14 x 1 ½" stainless steel screws along the bottom of the transom. (See Figure 3). Make ⅜" pilot holes for mounting screws. Assemble mounting plates and tab, dip screws in marine epoxy before running in. Position trim tab between mounting plates before running screws tight. Snug screws down to secure mounting plates and trim tab to transom.

IMPORTANT NOTE FOR BOATS KEPT IN SALT WATER: The black finish of the trim tabs provides a barrier from electrolytic action. However, if the boat is kept in salt water for long periods of time, a zinc anode must be applied to the top side of each tab. To provide protection, the zinc must make good contact with the stainless steel. Therefore the coating under the zinc must be removed. Do not ground the tabs to other underwater appendages. The black finish does not provide anti-fouling protection and should be painted with anti-fouling paint if such protection is desired.



Bennett Marine • 550 Jim Moran Blvd • Deerfield Beach, FL 33442
Ph: 954-427-1400 • Fax: 954-480-2897 • Email: info@BennettTrimTabs.com
www.BennettTrimTabs.com